

CONNECTING WIRED DEVICES

Each router is equipped with two ethernet ports. These ports can be used to connect nearby devices, such as a TV set to box or gaming console.

If you're subscribed to EBOX Home Phone, please connect the Home Phone adapter to the first yellow port.





For general support for your Internet, or for additional self-help resources visit **ebox.ca/FAQ** or contact our Technical Support team at **1-844-323-EBOX (3269)**



SETTING UP YOUR FIBRE INTERNET SERVICE AND WI-FI NETWORK



A technician will complete your fibre installation inside your home.

This will take approximately 2-4 hours. The technician will test the fibre terminal/ONT, and leave it connected to the fibre Internet cable and powered on. CONNECT AND POWER DEVICES


Connect the ETHERNET cable from the fibre terminal to the blue WAN port on the router.

The light on the bottom of the router should proceed from white to blue, back to white and then remain steady on blue when configured. This can take about 15 minutes.




Go to Wi-Fi settings on a device you would like to connect, and search for available Wi-Fi networks.

Select the Wi-Fi Name (SSID) and enter the password (Wi-Fi Key) that matches those found on the bottom of your router. The password is case sensitive.



DOWNLOAD THE NOKIA WI-FI MOBILE APP TO MANAGE YOUR INTERNET

- · Customize your Wi-Fi Name and Password
- · Create a separate network for guests
- Parental controls



THAT'S IT,
YOU SHOULD NOW BE READY TO ENJOY
YOUR EBOX WI-FI!